


How to change the Revolution Platform:



1. Place the Revolution in front of you with the handle away from your body.



2. Two knobs on the standard 4" platform should be on the left side. Unscrew each knob counterclockwise by hand to remove them.



3. Push or pull the 4" platform to the right until it slides all the way out of the Revolution. The handle will spin as you do this. You can also turn the handle manually.



4. Replace the knobs in the 4" platform to keep them together. Tighten by hand in clockwise direction.



5. Align either end of the 12" platform into the grooves of the Revolution and push it through. You're ready to die cut!

Unlike the standard 4" platform, there are no teeth on the underside of the 12" platform. Gears are not necessary due to the length of the platform.

How to die cut with the Revolution 12" Platform:



SNAP Place die(s) with design side up inside indentation on the magnetic 12" platform. Nothing should overlap or hang off the edge.

Caution! There are no stops on the 12" platform to prevent it from sliding out of the Revolution during use.



SET Place paper pattern side down, then place 12" cutting mat over die(s). **Apply pressure to hold paper and cutting mat in place and push the platform into the rollers of the Revolution.**



SPIN Spin handle to roll platform through tool. Remove die cut from paper.

